




ELLA+ROSS

Assembly Instructions



TRUMAN









Acrylic Coffee Table

ASSEMBLY INSTRUCTIONS


Please read the instructions carefully before beginning assembly. Ensure that you have all parts before assembly.

Place all parts on a soft and flat surface that is free of any debris to prevent scratches.


We're here to help - contact our Customer Service team by emailing cs@ellaandross.com for questions or concerns.

PARTS INVENTORY		
ID	DESCRIPTION	QTY
A	FRAME TOP 	1
B	FRAME BOTTOM 	1
C	GLASS 	1
D	LEGS 	4
E	MIRROR 	1
F	ANTI-SLIP BUMPERS 	8
G	ALLEN KEY 	1
H	SCREW 	8


1



2



3



Place anti-slip bumpers on each leg between the stainless steel and glass.

4

